

How To Use

Dry Core Bits

Attach the Alpha® Dry Core Bit onto your high-speed angle grinder by threading it onto the 5/8"-11 spindle.

Mark the location of holes that need to be drilled.

Use a template as a guide on the stone in order to avoid any mistakes during drilling process.

Clamp a piece of stone scrap under the stone being core drilled to prevent excessive chipping or “blowout” on the back side of the stone.

Proceed with drilling, pressing steadily until the dry core bit drills through the stone.

When drilling multiple holes, cool off the dry core bit by dipping it in cool water after each drilled hole.