

## How To Use

### **Summit Metal Bond Wheels**

Attach the Alpha® Metal Summit Wheel to your machine.

Adjust to the correct RPM range for your diameter wheel size

Adjust BAR pressure.

Set RPM range for your wheel diameter.

Turn on Water Supply.

Start your grinding process

Always review the operation manual for the proper setup procedure.